

Waters Lighting | Specification Sheet

Instruction notes for the installation of a WLM PECU02SW Part Night Operated switch.

Isolate mains supply to existing 2 Part Relay & lantern circuit

Remove 2 Part Relay body-assembly cover from relay base

Remove existing lantern circuit wire - (Lo) from Relay base

Mount PECU02SW switch on Backboard using the bracket provided

Connect PECU02SW Brown - Live wire to (Lo terminal) on Relay base

Connect PECU02SW Blue - neutral wire to N on relay base or Isolator

Connect PECU02SW PN out (Black wire) to Live - lantern circuit wire previously removed from (Lo) terminal in Relay base, using a suitable insulated terminal connector/block

Re-install the 2 Part Relay assembly onto relay base assembly

Turn on mains supply at Mains Isolator

Ensure that the low voltage 2 wire-2 Pin detector lead is installed back into the Relay assembly unit

press AUTO-TEST switch to TEST to prove circuit and lamp strikes

Return AUTO-TEST switch to AUTO mode for normal operation

The installation is now complete

